




#### 4. Locate location ID



#### 5. Add location to your Signagenow server

